
PROTECTIVE MAINTENANCE

As a general rule, epoxy floor coverings, including Hoover & Wells, Inc./Rez-Stone flooring systems, benefit from a complete maintenance program. Floors can wear and become defaced by heavy foot traffic grinding dirt and abrasives into the floor surface.

- A. Do not drag sharp objects across the floor surface.
- B. Do not weld over the floor system as moulton slag will burn the surface causing amber discoloration.
- C. Place wet caution signs in the event of standing water or oil.

CLEANING MAINTENANCE

- A. Routine sweeping and/or dusting is recommended to remove abrasive particles.
- B. As required, depending on the amount of traffic and laitance build-up on the floor, wash floor with warm water and detergent, following detergent manufacturer's directions. (Rez-Stone 1000 Soap Solution is recommended.)
 - 1. Wet mop solution onto floor surface.
 - 2. Scrub to loosen adhered dirt using stiff bristle nylon brush.
 - 3. Remove soiled wash water with mop, squeegee or wet vacuum and discard.
- C. Rinse floor thoroughly with clean water.
- D. For worn surfaces with wear scratches, the surface may be buffed using a lamb's wool pad. In addition, acrylic floor wax solution may be mop-applied to bring back shine.